

Get it out  
Loud!

Key A

Knob A

Key B

Knob B

Line out  
Power Switch  
Speaker

**CHIP TRICK**  
Chip Trick

**Soichi Terada Model**

Simple Power on : Chip Trick mode  
Key A+ Power on : Samba whistle Mode  
Key B+ Power on : Talk with Droid Mode  
for more detail visit <http://beatnic.jp>

Line Out

